

NOTICE


Proper Polarity And Voltage Is Critical For Operation.

Red To + Positive **Black To - Negative**

Driver Requires Voltage Source Of: 11-12 vdc.

Ambient Temperature Limit Is: 114° F

Using Outside These Limits Causes Overheat / Shutdown.



1. Attach Red Positive (+) cable clamp to the Positive (+) terminal of battery.
2. Attach Black Negative (-) cable clamp to the Negative (-) terminal of battery.
3. Turn the On/Off switch on the Model 3020 to the "On" position.